

CLEANING CHECKLIST

EVERY LABEL ROLL CHANGE	✓
Clean the print head with isopropyl alcohol and a lint-free cloth or cleaning pen	
Wipe down the platen (feed) roller	
Remove any visible label adhesive or residue	
Clear any bits of backing paper or dust from the label path	
Check label alignment guides and clean if needed	
Other	

ONCE A WEEK	✓
Wipe down the printer exterior with a soft, damp cloth	
Clean around sensors using a soft brush or compressed air	
Inspect for any print quality issues (fading, gaps, misalignment)	
Check the roller for wear or build-up	

ONCE A MONTH	✓
Perform a deep clean of all internal parts	
Inspect print head condition (lines or scratches)	
Test a label print for consistency and clarity	
Review print settings (darkness, speed) for current media	
Check for firmware updates or error logs	



SCAN THE QR FOR A MUCH DETAILED GUIDE